



# MAC FAUCETS

## PYOS Soap Dispensers Optional Remote control



Do not use  
Mode Button

A-14020



### INSTRUCTIONS

Use (s) AAA Alkaline batteries (2).

Hold remote control 5"-10" away from sensor and aim directly at the sensor eye

When a button is depressed indicator light will flash once indicating successful adjustment, twice (rapidly) indicating failed adjustment, or that the adjustment has reach maximum limit.

**DISTANCE:** This will adjust sensor range, press distance (-) button for short sensor range, distance (+) for longer sensor range

**TIME:** To adjust soap dispensing volume press time (-) for less soap, time (+) for more soap

**RESTART:** Press this button once, this will reset the sensor back to factory settings

**CLEAN:** Press once the button and the soap dispenser will automatically draw soap for 1 minute, through the nozzle, if the clear hose is filled with soap then it will dispense soap for 1 minute onto the sink

Optional remote control is designed for sensor range adjustment and to change the volume of soap which dispenser will dispense when used

One remote control is needed for many soap dispensers

### **Note:DO NOT USE MODE Button**

This is not for the PYOS soap dispensers, Using this button will disactivate the reverse setup on the sensor

### Limited Warranty

MAC FAUCETS warrant all MAC Faucets products to be free of defects for a period of one year from date of purchase. MAC FAUCETS will replace, free of charge, during this warranty period, parts that prove defective when properly installed and under normal use and service. Damage that occurs as a result of abuse, improper installation, environmental conditions, or improper application will void this warranty. Products or components that have been altered or in any way modified will not be covered under this warranty. This warranty does not cover installation or any other labor charges. This warranty does not cover shipping and handling of both replacement parts and returned defective parts. Defective products must be shipped back to MAC FAUCETS facilities with postage and handling prepaid, along with dated proof of purchase. Replacement parts are under warranty only for the remaining period under the initial warranty.